Licensed for Personal Use Only DO NOT DISTRIBUTE

These notes may contain copyrighted material!

They are for your own use only during this course.

Distributing them in anyway will be considered a breach of the Texas Tech academic integrity policy.

ASTR 2401

### Basic Spectroscopy

**Observational Astronomy** 

### Labs This Week

- \* We are done with observing for the semester.
- \* Lab time in evening to work on projects.
- Must come to your night, but may come to the other night for extra help.
- \* 8:00 (7:00?) 10:00

# **Physical Applications**

# Spectroscopy provides a host of information not attainable from imaging, including:

- Line profiles
  - \* broadening mechanisms (thermal, collisional, rotational)
  - velocity dispersions
  - \* outflows
- \* Spectral types of stars (temperature, surface gravity)
- Elemental abundances
- Radial velocities (redshifts)

### P Cygni Profile



### Formation of a P-Cygni Line- Profile



### Lyman-alpha Forest



### Stellar types



http://www.ifa.hawaii.edu/~barnes/ast110\_06/tlos/1105c.jpg





### Elliptical galaxy



### Elliptical galaxy



### **Emission line source**



http://spiff.rit.edu/classes/phys301/lectures/spec\_lines/spec\_lines.html

www.astrosurf.com/buil/us/spe6/planet.htm

## **Basic Spectrograph**

- \* Slit: isolates portion of sky that is imaged (not required)
- \* Collimator: makes the beam parallel
- Dispersive element: disperses light in wavelength
- \* Camera: focus light on detector, where the spectrum is recorded.

*The important characteristics of a spectrograph are the dispersion and resolution*.



### Dispersion

### \* Dispersion: $d\theta/d\lambda$

- \* How widely the light is spread (arcsec/Å or inverse)
- \* In physical detector units,
  - $dx = d\theta \, \bullet \, f_{cam}$  , so
  - $dx/d\lambda = d\theta/d\lambda \bullet f_{cam}$

This is the linear dispersion of the spectrograph (mm/Å).

\* Typical to quote inverse of linear dispersion (Å /mm)



### Dispersion

### \* Dispersion: $d\theta/d\lambda$

- \* Typical to quote inverse of linear dispersion (Å /mm)
  - "Low" dispersion: ~50-200 Å / mm (spectral types)
  - "Medium" dispersion: ~10-50 Å / mm (radial velocities)
  - "High" dispersion: <10 Å /mm(line profiles)</li>



### **Spectral Resolution**

#### Spectral resolution, or resolving power

- \* Defined as  $R = \lambda/\Delta\lambda$  (you saw this before with imaging filters).
- The optical system images the telescope focal plane on to the spectrograph detector plane.
- \* If a slit is used, the ratio of image scale at the slit vs. the detector plane is

$$\frac{x_{\text{det}}}{x_{\text{slit}}} = \frac{f_{\text{cam}}}{f_{\text{col}}}$$



## Why Slits?

- In order to limit the spreading of light of a single wavelength in the dispersion direction, a slit is usually employed at the telescope focal plane to mask the light from the object.
- \* To first order the possible spectral resolution will be set by the width, ω, (in the dispersion direction) of the image or the slit, as imaged in the spectrograph.
- \* The wavelength resolution is thus given by  $\delta \lambda = \omega d\lambda/dx$ .
  - \* or  $\delta \lambda = p d\lambda/dx$  if the pixel size of the detector,  $p > \omega$ .
- \* Must also include diffraction limit,  $\theta$ =1.22  $\lambda$ /D





### **Dispersive Elements: Prisms**

#### Prisms

- Simple dispersive elements
- Based upon refraction (Snell's law)
  - \* First surface disperses the light
  - \* Second surface disperses further
    - \* At this surface different wavelengths also have different angles of incidence



## **Dispersive Elements: Gratings**

### Diffraction Gratings

\* Use diffraction rather than refraction to disperse light



http://micro.magnet.fsu.edu/primer/java/interference/doubleslit

http://www.sparknotes.com/physics/optics/phenom/section2.rhtml

## **Dispersive Elements: Gratings**

### Diffraction Gratings

- \* Use diffraction rather than refraction to disperse light
- \* Angular separation of interference peaks is wavelength dependent



### **Dispersive Elements**

- **Transmission** gratings operate in a very similar fashion to Young's slit experiment, with a large number of slits.
- Reflection gratings consist of many closely-spaced grooves that act as parallel mirrors.
  - \* Constructive interference occurs when the path lengths light of rays reflecting off adjacent mirrors differs by n times the wavelength, where the integer n is the "order". 0th order is undispersed (white) light.
  - The grating and dispersion equations follow from the above definition.



#### Grating spectrograph





http://dtomono.freeshell.org/biblio/mos/021106\_Konzil/img006.gif

## **Dispersive Elements: Grisms**

### Grisms

- Combination of a prism with a transmission grating.
- Light at a chosen central wavelength passes through with no deviation in direction





### Long slit spectrum



http://www.chara.gsu.edu/~cantrell/m146.htm

### Long slit spectrum



http://www.chara.gsu.edu/~cantrell/m146.htm



### Multifiber spectrograph

\* Place fiber optic cables at locations of objects in the focal plane.

- \* Can be done either with a plate (as for multislit) or robotic positioning of the fibers
- Each fiber then feeds the light from the object to the spectrograph.

Right: 2dF spectrograph, showing fibers out the plate



(www.aao.gov.au/2dF)



#### 2dF 400 fibres 27/9/1997

CCD 1

CCD 2



## **Echelle Spectrographs**

- \* Echelle spectrographs are used for high resolution spectroscopy.
  - \* Typically operate with very high orders (m>50).
  - \* Second dispersive element is used to "cross-disperse" light.
  - \* Single object spectrum spread out in 2D.
  - \* Resolution can be very high (50-100k)



### Integral Field Units

- Combine some of the best features of imaging and spectroscopy.
  - Essentially get a spectrum for each pixel in the image.
- Certain tradeoffs...
- Several approaches
  - Fiber-fed
  - Image slicer



INTEGRAL- Mrk 273

http://www.ing.iac.es:8080/PR/newsletter/news3/mkn370s.jpg



#### FRIDA INTEGRAL FIELD SPECTROSCOPIC MODE

### Grating Seeing limited Frida **Diffraction limited Frida** IFU Slicer Telescope <u>A0</u> FRIDA System

11/7/05

FRIDA Conceptual Design

Reconstructed Images